



Ceramic Pizza Oven & BBQ

User Instructions

Please keep for
future reference




TOOLS FOR
ASSEMBLY
INCLUDED

We hope you are happy with your grill. In case of any problems please contact us and we will do our best to put it right! Thank you.

Bar-Be-Quick Rectella International
Ltd Bancroft Road Burnley Lancs
BB10 2TP

© 2022 Rectella International.

Call: +44 (0)1282 478200



User Instructions - Please keep for future reference

IMPORTANT

Carefully remove any packaging before use.

Read these instructions in their entirety and retain them for future reference.

These instructions form part of the product.

Take note of all of the safety warnings listed in these instructions.

These instructions should be stored with the product.

This product is for domestic use ONLY and should not be used commercially or for contract purposes.

NOTE: 'Crazing' can occur on this product but this is normal.

ABOUT YOUR PIZZA OVEN

Dating back 4000 years ago archaeologists have discovered large clay vessels thought to be early incarnations of the Pizza Oven. Since then it has evolved in many ways; removable lid, added draft door for better heat control and the switch from wood to charcoal as the primary fuel. In Japan the Mushikamado was a round clay pot with a removable domed lid designed for steaming rice. The name 'Pizza Oven' is, in fact, the Japanese word for 'stove' or 'cooking range'. This name was adopted by the Americans and has now become a generic term for this style of ceramic cooker.

Pizza Ovens are extremely versatile. Not only can they be used for grilling or smoking but also pizzas, bread, pies and cookies can be baked effortlessly inside them. Due to their excellent heat retention properties, high temperatures can be achieved and maintained by precise control of air flow via the top and bottom vents. High temperatures are ideal for fast cooking burgers and sausages whilst low heats will cook larger joints over a longer period of time. Why not try adding some wood chips to the charcoal or try combining different flavour wood chips to make your meats even more flavoursome.

WARNINGS – CAUTION!

- **This product is intended FOR OUTDOOR USE ONLY. DO NOT use indoors.**
- **ALWAYS keep children and pets at a safe distance from the oven when in use.**
- **NEVER leave a burning fire unattended.**
- **DANGER of carbon monoxide poisoning – NEVER light this product or let it smoulder or cool down in confined spaces.**
- **DO NOT use this product in a tent, caravan, car, cellar, loft or boat.**
- **DO NOT use under any awnings, parasols or gazebos.**
- **FIRE HAZARD – Hot embers may emit while in use.**
- **CAUTION - DO NOT use petrol, white spirit, lighter fluid, alcohol or other similar chemicals for lighting or relighting. Use only firelighters complying to EN1860-3.**
- **It is highly recommended that you use lump charcoal in your Pizza Oven. It burns for longer and produces less ash which can restrict the airflow.**
- **DO NOT use coal in this product.**
- **IMPORTANT: When opening the lid at high temperatures it is essential to lift the lid only slightly, allowing air to enter slowly and safely, preventing any backdraft or flare-ups that may cause injury.**
- **ALWAYS follow the FOOD COOKING INFORMATION stated on page 4 of this instruction manual.**
- **DO NOT use the Pizza Oven on decking or any other flammable surfaces such as dry grass, wood chips, leaves or decorative bark.**
- **Ensure that the Pizza Oven is positioned at least 2 metres away from flammable items.**
- **DO NOT use this Pizza Oven as a furnace.**
- **ATTENTION: This product will become very hot, DO NOT move it during operation.**
- **ALWAYS USE heat resistant gloves when handling hot ceramics or cooking surfaces.**
- **Allow the unit to cool down completely before moving or storing.**
- **Always inspect the unit prior to use for fatigue and damage and replace as and when necessary.**

CURING THE PIZZA OVEN

- To start a fire place rolled up newspaper with some lighter cubes or solid firelighters on the charcoal plate (7) in the base of the Pizza Oven. Then place 2 or 3 handfuls of charcoal over the top of the newspaper.
- **DO NOT** use petrol, white spirit, lighter fluid, alcohol or other similar chemicals for lighting or relighting.
- Open the bottom vent and light the newspaper using a long nosed lighter or safety matches.
- **DO NOT** overload the unit with fuel – if the fire is too intense this could damage the Pizza Oven.
- Leave until all the fuel is used and extinguished.
- If the first burns are too high it could damage the felt gasket seal before it has had the chance to mature properly.
- After first use inspect all fasteners for tightness. The metal band connecting your lid to the base will expand from the heat and this could become loose. It is recommended you check and if necessary tighten the band with a spanner.
- You can now use your Pizza Oven as normal.

EXTINGUISHING

- To extinguish unit – stop adding fuel and close all the vents and the lid to allow the fire to die naturally.
- **DO NOT** use water to extinguish the charcoals as this could damage the Pizza Oven.

Care and safe use guidelines

STORAGE

- When not in use, and if stored outside, cover the Pizza Oven once completely cooled with a suitable rain cover.
- The chrome plated cooking grill is **NOT** dishwasher safe; use a mild detergent with warm water.
- When using the Pizza Oven push down on both of the locking wheels to stop the unit moving about during use.
- It is recommended the Pizza Oven be stored under cover in a garage or shed over winter for complete protection.

CLEANING

- The Pizza Oven is self cleaning. Heat it up to 260°C for 30 minutes and it will scorch off all of the food and debris.
- DO NOT** use water or any other types of cleaning product to clean the inside of your Pizza Oven. The walls are porous and will absorb any fluids used, this could cause the Pizza Oven to crack. If the soot becomes excessive then use a wire brush or the ash tool (not supplied) to scrape off the carbon remnants before the next use.
- To clean the grills and grates use a non-abrasive cleaner once the unit has fully cooled.
- To clean the outer surface wait until the Pizza Oven is cool and use a damp cloth with a mild detergent.

MAINTENANCE

- Tighten the bands and oil the hinge 2 times a year or more if needed.

LIGHTING, USAGE AND CARE INFORMATION

- Ensure the Pizza Oven is positioned on a permanent, flat, level, heat resistant non-flammable surface away from flammable items.
- Ensure the Pizza Oven has a minimum of 2m overhead clearance and has a minimum 2m clearance from other surrounding items.
- To start a fire place rolled up newspaper with some lighter cubes or solid firelighters on the charcoal plate (7) in the base of the Pizza Oven. Then place 2 or 3 handfuls of charcoal over the top of the newspaper.
- DO NOT** use petrol, white spirit, lighter fluid, alcohol or other similar chemicals for lighting or relighting.
- Open the bottom vent and light the newspaper using a long nosed lighter or safety matches. Once it has caught, leave the bottom vent and lid open for about 10 minutes to build a small bed of hot embers.
- Allow the charcoal to heat up and be kept red hot for at least 30 minutes prior to the first cooking on the Pizza Oven. **DO NOT** cook before the fuel has a coating of ash.
- It is recommended you don't stoke or turn the coals once they are alight. This allows the charcoals to burn more uniformly and efficiently.
- Once alight **ONLY** use heat resistant gloves when handling hot ceramics or cooking surfaces.
- See below for cooking instructions depending on temperature and duration.

LOW TEMPERATURE COOKING GUIDE

- Light the charcoal according to the the instructions above. **DO NOT** move or stoke the coals once lit.
- Open the bottom vent fully and leave the lid open for about 10 minutes to build a small bed of hot embers.
- Monitor the Pizza Oven until it has risen to the desired temperature. See page 4 for a temperature cooking guide.
- Fully close the bottom vent to maintain the temperature.
- You are now ready to use the Pizza Oven for cooking on.
- IMPORTANT:** When opening the lid at high temperatures it is essential to lift the lid only slightly, allowing air to enter slowly and safely, preventing any backdraft or flare-ups that may cause injury.
- ALWAYS** follow the **FOOD COOKING INFORMATION** stated on page 4 of this instruction manual.
- ALWAYS** use heat resistant gloves when handling hot ceramics or cooking surfaces.

SMOKING GUIDE

- Follow the instructions above as if you were starting a slow cook.
- Monitor the Pizza Oven until it has risen to the desired temperature. See page 4 for a temperature cooking guide.
- Leave the bottom vent slightly open.
- Close the top vent and continue to check the temperature for a few more minutes.
- Using heat resistant gloves sprinkle the wood chips in a circle over the hot charcoal.
- You are now ready to use the Pizza Oven to smoke on.
- TIP:** Soak your wood chips or cooking planks in water for 15 minutes to prolong the smoking process.
- IMPORTANT:** When opening the lid at high temperatures it is essential to lift the lid only slightly, allowing air to enter slowly and safely, preventing any backdraft or flare-ups that may cause injury.
- ALWAYS** follow the **FOOD COOKING INFORMATION** stated on page 4 of this instruction manual.
- ALWAYS** use heat resistant gloves when handling hot ceramics or cooking surfaces.

Care and safe use guidelines

HIGH TEMPERATURE COOKING GUIDE

- Light the charcoal according to the the instructions on page 3.
- Close the lid and fully open the top and bottom vents.
- Monitor the Pizza Oven until it has risen to the desired temperature. See page 4 for a temperature cooking guide.
- Close the top vent half way and continue to check the temperature for a few more minutes.
- You are now ready to use the Pizza Oven for cooking on.
- IMPORTANT:** When opening the lid at high temperatures it is essential to lift the lid only slightly, allowing air to enter slowly and safely, preventing any backdraft or flare-ups that may cause injury.
- ALWAYS** follow the **FOOD COOKING INFORMATION** stated on page 4 of this instruction manual.
- ALWAYS** use heat resistant gloves when handling hot ceramics or cooking surfaces.







FOOD COOKING INFORMATION

- DO NOT** cook until the fuel has a coating of ash.
- Please read and follow this advice when cooking on your Pizza Oven.
- Always wash your hands before and after handling uncooked meat and before eating.
- Always keep raw meat away from cooked meat and other foods.
- Before cooking ensure grill surfaces and tools are clean and free of old food residues.
- DO NOT** use the same utensils to handle cooked and uncooked foods.
- Ensure all meat is cooked thoroughly before eating.
- CAUTION** – eating raw or under cooked meat can cause food poisoning (e.g. bacteria strains such as E.coli).
- To reduce the risk of under cooked meat cut open to ensure it is cooked all the way through.
- CAUTION** – if the meat has been cooked sufficiently the meat juices should be clear and there should be no traces of pink/red juice or meat colouring.
- Pre-cooking larger pieces of meat and joints is recommended before finally cooking on your grill.
- After cooking on your Pizza Oven always clean the grill cooking surfaces and utensils.

REFUELLING


- With the vents closed, the Pizza Oven stays at a high temperature for several hours. If you require a longer cooking time (e.g when roasting a whole joint or slow smoking), it may be necessary to add more charcoal. Just add some additional charcoal and continue as above.

COOKING TEMPERATURE GUIDE

Slow cook / Smoke (110°C-135°C)		Top vent	Bottom vent
Beef Brisket	2 Hrs per lb.		
Pulled Pork	2 Hrs per lb.		
Whole Chicken	3-4 Hr.		
Ribs	3-5 Hrs.		
Roasts	9+ Hrs.		
Grill / Roast (160°C-180°C)		Top vent	Bottom vent
Fish	15-20 Min.		
Pork Tenderloin	15-30 Min.		
Chicken Pieces	30-45 Min.		
Whole Chicken	1-1.5 Hrs.		
Leg of lamb	3-4 Hrs.		
Turkey	4 Hrs.		
Ham	5 Hrs.		
Sear (260°C-370°C)		Top vent	Bottom vent
Steak	5-8 Min.		
Pork Chops	6-10 Min.		
Burgers	6-10 Min.		
Sausages	6-10 Min.		

Open  Closed 

Parts List




Prior to assembly, read the instructions carefully. Check all parts against the parts list. Carry out assembly on a soft surface to avoid scratching the paint. Please retain this information for future reference.

For ease of assembly only loosely tighten bolts and then tighten fully when assembly is complete.


WARNING - DO NOT over tighten bolts; only tighten with moderate pressure to avoid damaging the bolts or components of the Kamado Grill.

Assembly instructions

IMPORTANT - Remove any packaging before use, but retain the safety instructions and store them with this product. Ensure that the lid is closed prior to assembly.




STEP 1 - Position the parts on a flat surface that will not scratch the finish of the nest components, paying close attention to the joint overlap in the illustration above the 2pcs Upper cross brace(4&5) and 2pcs Lower cross brace(2&3). Using the given hardware and hand tighten the braces with screw A + nut F.




- STEP 2 - (Joining the two halves assembled in step 1) Stand the section 1 upright, and place the upper cross braces (4&5) close to section 1. Inserting truss head screw C through the hole of section 1 and section 4&5 and install G Keps nut and tighten securely.

- STEP 3 - (Installing the lower cross braces and casters) Place the assembled lower cross braces (2&3) under section 1, Stand the section 6 upright to make it close to section 1 and section 4&5. Inserting screw B through section 4&5 and section 6, install G Keps nut and tighten securely. Next insert the threaded caster stem through the hole in the end of the lower cross brace then through the riser and finally the riser brace. Install (I) flat washer and (I) Keps nut, repeat this at the remaining (3) caster locations and securely tighten.




- STEP 4 - As picture, put wheels 7 in front, and wheels with brake at the back.
- STEP 5 - To place the Oven on the cart first remove all of the items that are inside of the grill to make lifting easier.
- STEP 6 - Use a minimum of two people when lifting the Oven onto the cart. Place one of your hands in the bottom vent of the Oven and the other under the grill. Lifting by the hinge or the side tables could result in injury and damage to the product.
- STEP 7 - Position the nest upright on a flat level surface with the help of an assistant you can now place the oven into the nest. Position the oven so the vent door is accessible between two of the risers and gently push downward on the oven to seat it in the nest.




STEP 8 - When the Oven is securely placed on the cart add the firebox (13), charcoal plate (12), upper ring (11), cooking grill (16), heat deflector (15), trigonal frame(10), pizza stone (9) inside of the Pizza Oven as displayed in the assembly diagram.

STEP 9 - Press down on the castor levers (8) to lock the castor wheels to ensure the Pizza Oven can not move when in use.




- STEP 10 - Attach the lid buffer top plate (17) to the lid of the Pizza Oven (14) by using the 2x pre-attached bolts and dome headed nuts.
- STEP 11 - Attach the lid buffer (18) to the Pizza Oven (14) by using the 2x pre-attached bolts and dome headed nuts.
- STEP 12 - To attach the handle (20) to the lid of the Pizza Oven (14) start by attaching 2x handle brackets (19) using the 2x pre-attached bolts and dome headed nuts. Attach the handle (20) to the brackets (19) using 2xbolts (D) and nuts (F).

Ensure that the top vent bolt is on the left hand side when assembling it.




- STEP 13 - To attach the top vent (21) to the Pizza Oven (14) place it on top and align both the bolt holes. Secure using 2x bolts (E) and nuts (F). Ensure that the top vent bolt is on the left hand side when assembling it.



STEP 14 - Attach the 2x table brackets (23) to the Pizza Oven (14) using the 4x pre-attached bolts and dome headed nuts per bracket. Please note the position shown in the above diagram

STEP 15 - Attach the 2x table brackets (24) to the Pizza Oven (14) using the 4x pre-attached bolts and dome headed nuts per bracket. Please note the position shown in the above diagram.



STEP 16 - Insert the 2x table hinge into each of the table brackets (23 & 24).

The **Pizza Oven** is now ready to use but please ensure that you have read the curing instructions thoroughly prior to use.



Bar-Be-Quick - Rectella International Ltd Bancroft Road Burnley Lancs BB10 2TP.
<https://www.barbequick.com/grillguide/>
Call: +44 (0)1282 478200

BQ3838-1a